


CamTrax64



 **Camnetics**
INCORPORATED

Copyright Notice(版权声明)

Copyright © 1997-2008 Camnetics, Inc.



Camnetics, Inc.

926 Autumn Woods Lane Oregon, WI 53575 USA 1-608-835-2378
support@camnetics.com

file date: 2009-11-02

目录

Copyright Notice(版权声明).....	2
Camnetics, Inc.	2
Introduction(介绍)	15
Definitions(定义):.....	16
CAD.....	16
Component(组件).....	16
Part(零件)	16
Assembly(装配)	16
Annotation(注释).....	16
Model(模型).....	16
Cam(凸轮).....	16
Path(路径)	16
Segment(分割).....	16
Common Angle(常见角度)	17
Motion Type Abbreviations(运动类型缩写).....	17
Double Follower(双从动).....	18
Starting CamTrax64(开始 CamTrax64).....	18
CamTrax64 Menus(菜单)	22
File(文件).....	22
New(新建)	22
Open Components(打开组件).....	22
Open Assemblies(打开装配).....	22
Add Path from File(从文件中添加路径).....	22
Save Path As(路径另存为).....	22
Save Component(保存组件)	22
Save Component As(组件另存为).....	23
Save All(全部保存)	23
Save All As(全部另存为)	23
Save Assembly As(装配另存为)	23
Print the CamTrax64 Window(打 CamTrax64 窗口)	23

Capture CamTrax64 screen to a file(捕捉 CamTrax64 屏幕到一个文件夹).....	23
Capture CamTrax64 screen to the clipboard(捕捉 CamTrax64 屏幕到剪贴板)	23
Capture CamTrax64 screen and open in bit map editor(捕捉 CamTrax 屏幕并在位图编辑器中打开)	24
Empty Clipboard(清空剪贴板).....	24
Recent files(最近使用的文件)	24
Exit(退出).....	24
Edit(编辑)	24
Remove Segment(删除分割)	24
Remove Path(删除路径)	24
Remove Cam Blank(删除凸轮毛坯).....	24
CAD	25
Create CAD Models and Assembly(创建 CAD 模型和装配)	25
Insert Segment List into Drawing(插入分割列表到工程图).....	25
Edit CAD Models(编辑 CAD 模型).....	25
Component Template File(零件模板文件).....	25
Assembly Template File(装配体模板文件).....	25
Fabrication(加工).....	25
Activate Fabrication(激活加工)	25
Process NC File(NC 程序文件).....	25
Simulate Fabrication(模拟加工).....	26
Save as Default Fabrication Settings(另存为默认加工设置).....	26
Open Default Fabrication Settings(打开默认加工设置).....	26
Save Fabrication Settings as(另存为加工设置).....	26
Open Saved Fabrication Settings(打开已保存的加工设置).....	26
View(视图).....	26
Redraw - fit all(重绘-适用所有).....	26
Set Drive Angle to 0(设置驱动器角度为 0).....	26
Show XY Readouts(显示 XY 读数)	27
Collapse Grid(折叠网格)	27
Expand Grid(展开网格)	27
Toolbars(工具栏).....	27

Open Chart Window(打开图标窗口)	27
Open Machine Layout Window(打开机构设计窗口)	27
Insert(插入)	28
Insert New Cylinder into Assembly(插入新圆柱体到装配).....	28
Insert New Cube into Assembly(插入新立方体到装配).....	28
Insert New Path into Active Blank(插入新路径到活动毛坯).....	28
Insert Segment into Active Path(插入分割到活动路径).....	28
Sample Cams(凸轮样品)	29
No Dwell(无停歇)	29
Single Dwell(单次停歇)	29
Dwell-Rise-Dwell-Return(停歇-升程-停歇-回程)	30
Oscillating Arm(摆动臂).....	30
Constant Velocity(等速)	31
Terminal Velocity(终端速度).....	31
Double Follower(双从动).....	32
Tools(工具).....	33
Copy Hub Top Side(复制轮毂顶端).....	33
Copy Hub Bottom Side(复制轮毂底端).....	33
Paste to Hub Top Side(粘贴到轮毂顶端)	33
Paste to Hub Bottom Side(粘贴段轮毂底端).....	33
Swap Hub Sides(互换轮毂边).....	33
Animation Speed(动画速度).....	33
Reverse Animation Direction(方向动画方向).....	33
Create Data Sheet(创建数据表)	33
Create XY File(创建 XY 文件)	34
Open install folder using Explorer(使用资源管理器打开安装目录).....	34
Options(选项).....	34
Help (帮助)	34
CamTrax64 Help Topics(CamTrax64 在线帮助主题).....	34
CamTrax64 Help for CAD(CamTrax64 的 CAD 帮助).....	34
CamTrax64 Manual (PDF) (CamTrax64 手册)	34
CamTrax64 Quick Start Guide (PDF)(CamTrax64 快速入门指南)	35

Registration（注册）	35
Create an Email with registration information(创建带有注册信息的电子邮件)	35
View License Agreement(查看许可协议)	35
Check for Updates(检查更新)	35
About CamTrax64（关于）	35
Options（选项）	35
Color and Line Options(颜色和线条选项).....	36
Color Back Ground(背景颜色)	36
Color Cam Follower(从动凸轮颜色)	36
Color Intensity Cam Follower(从动凸轮颜色强度).....	36
Image Quality(图像质量)	36
Line Weight(线宽)	37
Shaded Display Near Side(着色显示边线)	37
Show Path Lines(显示路径线)	37
General Options(常规选项)	37
Animation Speed(动画速度).....	37
Collapse Grid on Startup(启动时折叠网格).....	37
Decimal Places(小数位数)	37
Default Units(默认单位).....	37
Fabrication File Extension Name(加工文件扩展名)	37
Grid Font(网格字体).....	37
Mouse Drag Speed(鼠标拖动速度)	38
Mouse Wheel Direction(鼠标滚轮方向).....	38
Show XY Readout(显示 XY 读数).....	38
Spin Increment(旋转增量).....	38
New Version Options(新的版本选项).....	38
New Version Check on Startup(启动时检查新版本).....	38
New Version is Available(可用新版本)	38
Oscillating Cam Options(摆动凸轮输出).....	38
Oscillating Cam Output(摆动凸轮输出).....	38
Settings, CAD(CAD 设置).....	39
CAD Version(CAD 版本)	39

Display Annotations in Upper Case(以大写形式显示注解)	39
Template File for Assembly(零件文件模板)	39
Template File for Component(装配体模板文件)	39
Cam Blank Cylinder(圆柱凸轮毛坯)	40
Cam Blank Data (Cylinder)(凸轮毛坯数据)(圆柱型)	40
AXIS(轴)	40
Blank Chamfer(毛坯倒角)	40
Blank Diameter(毛坯直径).....	40
Blank Height(毛坯高度)	40
Color Cam Blank(凸轮毛坯颜色)	40
Name Cam Blank(凸轮毛坯名称)	40
Path File(文件路径)	40
Units(单位)	40
Cam Rotation(凸轮旋转)	40
Cycle Time(循环时间)	40
Direction Rotation(旋转方向)	41
RPM(转速)	41
Cam Position(凸轮位置).....	41
X Delta(X 增量)	41
Y Delta(Y 增量)	41
Z Delta(Z 增量)	41
Hub Data(轮毂数据)	41
Bore Chamfer(孔倒角).....	41
Bore Diameter(孔直径).....	41
Hub Bottom Side Chamfer(轮毂底边倒角).....	41
Hub Bottom Side Diameter(轮毂底边直径).....	41
Hub Bottom Side Projection(轮毂底边长度)	41
Hub Top Side Chamfer(轮毂顶边倒角)	41
Hub Top Side Diameter(轮毂顶边直径)	42
Hub Top Side Projection(轮毂顶边长度).....	42
Keyway(键槽).....	42
Keyway Angle(键槽角度)	42

Mounting Bushing Modeling(安装衬套建模)	42
Mounting Bushing Side(安装衬套边).....	42
Mounting Split Taper Bushing(安装分裂锥形衬套).....	42
Standard Set Screw(标准紧定螺钉)	42
Cam Blank Cube(立方体凸轮毛坯)	43
Cam Blank Data (Cube)(凸轮毛坯)(立方体)	43
AXIS(轴)	43
Blank Length(毛坯长度)	43
Blank Thickness(毛坯厚度).....	43
Blank Width(毛坯宽度)	43
Cam Paths(凸轮路径).....	43
Cam Blank Date(凸轮毛坯日期)	43
Cam Blank Name(凸轮毛坯名称)	43
Units(单位)	43
Path Specifics(路径细节)	43
Name Path(路径名称)	43
Number of Segments(分割数)	44
Path Closed(路径关闭).....	44
Path Segments Continuous(连续分割路径).....	44
Path Surface(路径表面)	44
Path Type(路径类型)	44
Follower Data(从动数据).....	46
Crowned Follower(鼓形从动)	46
Dual Follower Separation(双从动分离)	46
Follower Size Dimensional(从动尺寸).....	47
Follower Size Nominal(从动公称尺寸)	47
Follower Type(从动类型).....	47
Heavy Stud(重型螺栓).....	48
Path Clearance(路径间隙)	48
Path Depth(路径深度)	48
Translating offset(平移偏移量).....	48
Oscillating Arm Data(摆动臂数据)	48

Arm Length(臂长度).....	48
Flip Quadrant(翻转象限)	48
Pivot X(X 枢轴)	49
Pivot Y(Y 枢轴)	49
Reaction Arm Length(反应臂长度)	49
Conjugate Data(共轭数据).....	49
Conjugate Follower Angle(共轭从动角度).....	50
Conjugate Follower Center Distance(共轭从动中心距离).....	50
Conjugate Master Cam Path(共轭主凸轮路径)	50
Load Data(加载数据)	50
Contact Width(接触宽度).....	50
External Forces(外力)	50
Friction Coefficient(摩擦系数)	50
Modulus of Elasticity Follower(从动弹性模量)	50
Modulus of Elasticity Path(路径弹性模量).....	50
Spring Compresses(弹簧压缩)	51
Spring Compression at Cam Zero(凸轮弹簧压缩零).....	51
Spring Rating(弹簧等级)	51
Weight of Accelerated Elements(加速元素重量)	51
Cam Segments(凸轮分割).....	51
Start Angle(开始角度).....	51
End Angle(结束角度)	51
Start Offset(开始偏移量)	51
End Offset(结束偏移量)	51
Start Arm Angle(开始臂角度)	52
End Arm Angle(结束臂角度).....	52
Motion Type(运动类型)	52
Configure(配置)	52
Precision(精度).....	52
Color(颜色).....	53
Oscillating Followers(摆动从动).....	53
Segment Configuration(分割配置).....	53

Configuration(表面配置).....	54
beta.....	54
h.....	54
h1.....	54
h2.....	54
n.....	54
theta 1	54
theta 2	55
Maximum Velocity and Accelerations(最大速度和加速度)	55
Max Negative Acceleration(最大负加速度).....	55
Max Positive Acceleration(最大正加速度).....	55
Max Velocity(最大速度).....	55
Truncation(舍去)	55
End Truncation by Angle(结束截断的角度).....	55
Start Truncation by Angle(开始截断的角度)	55
Buttons(按钮).....	55
Print(打印)	55
Cancel(取消)	55
Apply(应用)	56
OK(确定)	56
Configure Constant Velocity(等速配置).....	56
Cycle Data(周期数据).....	56
Cycle Time(循环时间)	56
Segment Angle(分割角度).....	57
Segment Displacement(分割移位)	57
Segment Time(分割时间).....	57
Constant Velocity Parameters(等速度参数).....	57
Accel Decel Type(加速减速类型)	57
Displacement of CV(等速度位移)	57
Velocity of CV(等速度速度).....	57
Angle of CV(等速度角度)	57
Time of CV(等速度时间).....	57

Minimum Velocity Allowed(最小允许速率).....	58
Maximum Velocity Allowed(最大允许速率).....	58
Symmetry(对称)	58
Symmetry(对称).....	58
Acceleration Displacement(加速度位移).....	58
Acceleration Angle(加速度角度)	58
Deceleration Displacement(加速度位移)	59
Deceleration Angle(减速度角度).....	59
Buttons and Slider Bar(按钮和滑块)	59
Chart Type (drop down selector)(图表类型(下拉选择器)).....	59
Cancel(取消)	59
Restore(还原).....	59
OK(确定)	59
Slider Bar(滑块).....	59
Configure Terminal Velocity()	60
Cycle Data().....	60
Cycle Time(循环时间)	60
Segment Angle(分割角)	60
Segment Displacement(分割位移)	60
Segment Time(分割时间).....	60
Configure(配置).....	61
TV Start Offset(终端速度开始偏移)	61
TV Start Angle(终端速度开始角度).....	61
TV End Offset(终端速度终止偏移).....	61
TV End Angle(终端速度终止角度).....	61
Terminal Velocity Parameters(终端速度配置).....	61
Motion Type(运动类型).....	61
Terminal Location(终端位置)	61
Displacement of TV(终端速度位移).....	62
Velocity of TV(终端速度速度)	62
Time of TV(终端速度时间)	62
Angle of TV(终端速度角度)	62

Pass Fail(通过失败).....	62
Configure User Points(配置用户点)	62
Data Area(数据区)	62
Apply(应用)	63
Cancel(关闭).....	63
OK(确定).....	63
Motion Types(运动类型)	63
Dwell(停歇).....	63
Cycloidal(摆线)	63
Harmonic(简谐)	63
Modified Sine(修正正弦)	64
Modified Trapezoid(修正梯形)	64
Cycloidal/Harmonic(先摆线/后简谐).....	64
Harmonic/Cycloidal(先简谐/后摆线).....	65
Constant Velocity(等速度)	65
Terminal Velocity(终端速度).....	65
Polynomial 8th Power Rise(多项式 8th 功率上升)	65
Polynomial 8th Power Fall(多项式 8th 功率下降).....	66
Polynomial 345(多项式 345)	66
Polynomial 4567(多项式 4567)	66
Polynomial 3456 Rise(多项式 3456 上升).....	66
Polynomial 3456 Fall(多项式 3456 下降)	66
Constant Acceleration(等加速度)	66
Double Harmonic Rise(双简谐上升)	67
Double Harmonic Fall(双简谐下降).....	67
User Points(用户点).....	67
By Pass(跳过忽略).....	67
Create CAD Models and Assemblies...(创建 CAD 模型和装配)	68
Options for creating cams and/or assemblies(用于创建凸轮或装配的选项).....	68
Create active cam and all paths. (创建活动凸轮和所有路径。)	68
Create active path on current active CAD part file(在当前激活的 CAD 零件文件 上创建活动路径).....	68

Create all cams and assembly(创建所有凸轮和装配)	69
Path creation options(路径创建选项)	69
Create single surface path only(仅创建单个路径表面)	69
Create individual path segments only(仅创建单独路径分割)	69
Create single surface path and individual segments (suppressed) (创建单一表面 路径和个别分割(压缩))	69
Browse CAD File Location(浏览 CAD 文件位置)	69
Create in "CAD"(在 CAD 中创建)	70
Edit CAD Models(编辑 CAD 模型).....	71
Link(连接)	71
Update CAD(更新 CAD)	71
Cancel(取消)	71
Close(关闭)	71
Procedure to edit a cam model in CAD(编辑凸轮 CAD 模型的过程)	71
Limitations to editing CAD models(编辑 CAD 模型的局限性)	72
Fabrication(加工).....	72
Finishing Tool(精加工工具).....	72
Diameter Finishing(直径精加工)	72
Feed Rate Finishing(进给速率精加工)	72
Stock for Finishing(坯料精加工)	72
Tool Number Finishing(工具号码精加工)	73
Depth Cuts Finishing(深度切割精加工).....	73
Number of Passes Finishing(程数精加工)	73
Spindle Speed Finishing(主轴转速精加工)	73
Roughing Tool(粗加工工具)	73
Diameter Roughing(直径粗加工)	73
Feed Rate Roughing(进给速率粗加工)	73
Tool Number Roughing(工具号码粗加工)	73
Depth Cuts Roughing(深度切割粗加工).....	73
Spindle Speed Roughing(主轴转速粗加工)	73
Cuts(切割)	74
Surfaces to Cut(表面切割)	74

Cuts(切割)	74
Feed Rate Z(进给速率 Z)	74
Mill Direction(铣刀方向)	74
Coolant(冷却液)	74
Controller(控制器)	74
Machine Controller(机器控制器)	74
Program Number(程序号)	75
Mirror X Direction(镜像 X 方向)	75
Mirror Y Direction(镜像 Y 方向)	75
Mirror A Direction(镜像 A 方向)	75
Simulate Fabrication(模拟加工)	76
Buttons(按钮)	76
Open(打开)	76
Edit(编辑)	76
Close(关闭)	76
VCR Controls(VCR 控件)	77
Tool Bars(工具栏)	78
Insert(插入)	78
Standard(标准)	78
Standard Views(标准视图)	78
View(视图)	80
Simulation(模拟)	81
Mouse controls(鼠标控制)	82
Current Mouse Position(当前鼠标位置)	82
On Screen Measurements(屏幕上测量)	82
Mouse wheel(鼠标滚轮)	82
Middle Mouse Button (wheel) (鼠标中键 (滚轮))	82
Chart(图表)	83
Machine Layout(机构布局)	84
Cam Design 101(凸轮设计)	85
Common Cam Design Errors(常见凸轮设计错误)	85
Under Cutting(下切割)	85

Motion types that should not follow one another.....	85
Configuring a Constant Velocity Motion Type(配置等速度运动类型).....	86
Configuring a Terminal Velocity Motion Type(配置终端速速运动类型)	88

Introduction(介绍)

CamTrax64 is an object oriented/property driven cam design program. It is not the intent of CamTrax64 to replace your CAD system but to augment the CAD system with a user interface that will allow the cam designer to accurately visualize the cam components before they are modeled in the CAD system.(**CamTrax64** 是一个物件导向/属性驱动凸轮设计程序。它的目的不仅仅是取代 CAD 系统，而是增加 CAD 系统用户界面，使凸轮设计师能够在 CAD 系统上建模前准确地设想凸轮组件。)

A CamTrax64 base component is either a cylinder or a cube. A cylinder can have paths inserted on both ends and/or the cylindrical surface. A cube can have paths inserted on the upper or lower surface. Each path has a single cam follower. This follower can be translating or oscillating. A path may also be a dual follower (two cam followers of the same diameter) so a ridge is created along the centerline of the path.(一个 **CamTrax64** 的基本组成是一个圆柱体或一个立方体。一个圆柱体有路径插入两端或圆柱表面。 一个立方体有路径插入上下表面。每个路径都有一个单独的凸轮从动，这个从动可以平移或摆动。一个路径还能变成一个双从动件(即两个直径相等的凸轮从动)，所以沿着路径中心线会有一条脊线。)

A path may also be conjugate to another path (master). The conjugate path may have a follower of a different diameter than the master path.(一个路径还可以变成共轭到另一条路径（主体）。这个共轭路径有与主路径直径不同的从动件。)

CamTrax64 is programmed in the USA using 100% renewable energy.(在美国， **CamTrax64** 运用 100% 可再生能源进行编程。)

Definitions(定义):

CAD

CAD (Computer Aided Design) is the system this program was compiled to run with, either as an add-in or an add-on. (CAD 计算机辅助设计) 是一种系统，用于编辑程序运行或作为一个插件或一个扩展。)

Component(组件)

A component is a single CamTrax64 cam base object, a cube or cylinder. (组件是一个单独的 CamTrax64 凸轮基本物件，一个立方体或圆柱体。)

Part(零件)

A part is a single CAD part document file that contains one cam base object and one or more cam paths. (一个零件是单独的 CAD 部件文档文件，包括一个凸轮基本物件和一个或多个凸轮路径。)

Assembly(装配)

An assembly is a group of CamTrax64 components or a group of CAD parts. (装配是一组 CamTrax64 组件或一组 CAD 部件。)

Annotation(注释)

An annotation is a text or Excel note placed on the CAD part or drawing document. (注释是一个放置在 CAD 部件或图纸文档的文本或 Excel。)

Model(模型)

A model is a CAD part document. (模型是一个 CAD 组件文档。)

Cam(凸轮)

A cam is a cylinder or cube that contains one or more paths. (凸轮是指一个圆柱体或立方体包含一个或多个路径。)

Path(路径)

A path is a groove or ridge (in the case of dual cam followers) in a cam. A path is made up of one or more segments. A single cam may have multiple paths. (一个路径是指在凸轮里的一个槽或脊 (对于双凸轮从动)。一个路径由一段或多段组成。一个单独的凸轮可能有多个路径。)

Segment(分割)

A segment is a part of a path from one angle to another. Each path will have one or more segments. Each segment is defined by a start and stop position of angle and offset. There is a specified motion type for each segment. Most motion types can be further configured for that particular segment. The precision or number of points per degree can be specified;

the default is 1.0 per degree. Each segment's display color may be changed.

(分割段是路径从一个角度到另一个角度的一段。每个路径会有一个或多个分割段，每个分割段都被角度和平移的启动或停止方位控制，每一段有一个指定的运动类型，大多数运动类型可以进一步设置为特定的分割段。每个度的精度和点数都能指示。)

Common Angle(常见角度)

The common angle is a line extending from a disk cam center to the pivot point of an oscillating arm. (常见角度是指从盘形凸轮中心到摆臂枢轴点之间的线。)

Motion Type Abbreviations(运动类型缩写)

The CAD feature manager will display the name of the extrusions or lofts for each segment. The first number is the number of the path. The second number is the number for the segment. If the segment number is "0" then it is a single surface extrusion or loft, which may contain more than one segment. (CAD 功能管理器将会显示每个分割段挤压或倾角的名称，第一个数字就是路径的数量，第二个数字是段号。如果段号为“0”，那么挤压或倾角会在一个表面，可能包含多个分割段。)

The next set of characters defines the type of motion (not valid for single surface). (以下字符为运动类型定义(不适合单一表面)。)

BP = By Pass(跳过忽略)

CA = Constant Acceleration(等加速度)

CV = Constant Velocity(等速度)

Cyc = Cycloidal(摆线)

CH = Cycloidal/Harmonic(先摆线/后简谐)

HF2 = Double Harmonic Fall(双简谐上升)

HR2 = Double Harmonic Rise(双简谐下降)

Dw = Dwell(停歇)

UP = User Points(用户点)

Har = Harmonic(简谐)

HC = Harmonic/Cycloidal(先简谐/后摆线)

MS = Modified Sine(修正正弦)

MT = Modified Trapezoid(修正梯形)

P345 = Polynomial 345(多项式 345)

P3456F = Polynomial 3456 Fall(多项式 3456 上升)

P3456R = Polynomial 3456 Rise(多项式 3456 下降)

P4567 = Polynomial 4567(多项式 4567)

P8F = Polynomial 8th Power Fall(多项式 8th 功率上升)

P8R = Polynomial 8th Power Rise(多项式 8th 功率下降)

TV = Terminal Velocity(终端速度)

The next two sets of numbers will be the start and end angles for the segment. (接下来的两组数字是分割段的开始及结束角度。)

The next two sets of numbers will be the start and end offsets for the segment. (接下来的两组数字是分割段的开始及结束位移。)

For example, a featured named "1-3-HC 90.0 240.0 6.000 2.000" will define the third segment of the first path that is a Harmonic/Cycloidal motion type. The segment starts at 90.0 degrees and ends at 240.0 degrees. The starting offset is 6.000 and ends at 2.000 offset. (例如，一个特色的命名"1-3-HC 90.0 240.0 6.000 2.000"将定义第一路径的第三段，即先简谐/后摆线运动类型。这个分割段从 90° 开始，240° 结束，开始位移是 6.000，结束为 2.000。)


Do not rename the beginning ("1-3-") of these features if there is any chance that the cam may be changed using CamTrax64 in the future. CamTrax64 needs to know the path and segment designations to identify the correct path when editing the segment. (如果在将来有任何机会凸轮可能运用 camtrax64 得到改变，请不要重命名这些功能的开始 ("1-3-")。当编辑分割段时，CamTrax64 需要知道这个路径和段名。)

Double Follower(双从动)


A cam with a double follower has two followers separated by a specified distance. This creates a "ridge" that the followers ride against. One of the advantages to this type of system is that the follow rotation never needs to change direction as a single follower would in a positive type of path. (双从动凸轮有两个被规定的距离隔开的从动，创建的“脊线”即从动反向控制。这种类型系统的好处之一就是从动旋转不需要改变方向，作为一个单独的从动在路径中将会是一个积极的类型。)

Starting CamTrax64(开始 CamTrax64)


This release of CamTrax64 requires it to be started using the Windows Start menu. (此版本 camtrax64 需要运用 Windows 开始菜单去启动。)



CamTrax64 Main Window (Camtrax64 主窗口)



CamTrax64 Chart Window (CamTrax64 图表窗口)



CamTrax64 Machine Layout Window (CamTrax64 机器布局窗口)

CamTrax64 Menus(菜单)

File(文件)

New(新建)

New removes all components and clears CamTrax64 to start a new assembly or component. (通过删除所有组件和清除 **camtrax64** 来启动一个新的装配和组件。)

Open Components(打开组件)

Open Components opens a previously saved component document. Component files have .ctxcom as the extension. (打开组件：打开之前保存的组件文档，组件文件里“**ctxcom**”即扩展。)

Open Assemblies(打开装配)

Open Assemblies opens a previously saved assembly document. Assembly files have .ctxasm as the extension. (打开装配：打开之前保存的装配文档，装配文件里“**ctxcom**”即扩展。)

Add Path from File(从文件中添加路径)

Add Path from File inserts an existing path into the component. The path data is not linked to the path from the file, so any changes made to the inserted path will not be reflected in the path file. (从文件添加路径，插入现有的路径到组件中，路径数据没有连接到文件中的路径，所以插入路径的任何改变都不会反映到文件中的路径。)

Save Path As(路径另存为)

Save Path As saves the current active path. Path files have ctxpth as the extension. (将“保存路径为”保存到当前活动路径，路径文件夹有“**ctxpth**”作为扩展选项)

Save Component(保存组件)

Save Component saves the active component. The component name will change to reflect the name of the file. Component files have .ctxcom as the extension. (将“保存组件”保存到有效组件中，这个组件名称将会改变以反映文件名称。组件文件中有“**ctxcom**”作为扩展选项)

Save Component As(组件另存为)

Save Component As saves and changes the name of the active component. The component name will change to reflect the name of the file. Component files have .ctxcom as the extension.

(将“保存组件为”保存并改变有效组件名称，这些组件名称将会改变以反映文件名称，组件文件中有’ ctxcom”作为扩展选项。)

Save All(全部保存)

Save All saves the assembly. The assembly will change to reflect the name of the file. Assembly files have .ctxasm as the extension and component files have the .gtc extension.

Save All As(全部另存为)

Save All As saves and changes the name of the assembly and components. The assembly will change to reflect the name of the file. Assembly files have .ctxasm as the extension and component files have the .ctxcom extension. (将“保存全部”保存到装配中，这个装配将被改变以反映文件名称，装配文件有“.ctxasm”和“.gtc”作为扩展选项。)

Save Assembly As(装配另存为)

Save Assembly As saves and changes the name of the assembly. The assembly will change to reflect the name of the file. Assembly files have .ctxasm as the extension.

Print the CamTrax64 Window(打 CamTrax64 窗口)

Print CamTrax64 Window prints the CamTrax64 window using the default printer, including borders.

Capture CamTrax64 screen to a file(捕捉 CamTrax64 屏幕到一个文件夹)

Capture CamTrax64 screen to a file captures the CamTrax64 screen, including borders, to a bit map file.

Capture CamTrax64 screen to the clipboard(捕捉 CamTrax64 屏幕到剪贴板)

Capture CamTrax64 screen to the clipboard captures the CamTrax64 screen, including borders, to the clipboard.

Capture CamTrax64 screen and open in bit map editor(捕捉 CamTrax 屏幕并在位图编辑器中打开)

Capture CamTrax64 screen and open in bit map editor captures the CamTrax64 screen, including borders, to the default bit map editor.

Empty Clipboard(清空剪贴板)

Empty Clipboard clears the clipboard of any data. This will free up any memory the screen capture is using.

Recent files(最近使用的文件)

Recent files displays recent files. Click on the recent file to open it in CamTrax64.

Exit(退出)

Exit closes CamTrax64. The user is prompted to save any unsaved data.

Edit(编辑)

Remove Segment(删除分割)

Remove Segment removes the active segment from the active path. There must be more than one segment on the path to remove a segment. The user is prompted before the segment is removed.

Remove Path(删除路径)

Remove Path removes the active path from the cam blank. There must be more than one path on the cam blank to remove a path. The user is prompted before the path is removed.

Remove Cam Blank(删除凸轮毛坯)

Remove Cam Blank removes the active cam blank from the assembly. There must be more than one cam blank to remove a cam blank from the assembly. The user is prompted before the cam blank is removed. All paths associated with the cam blank will be removed.

CAD

Create CAD Models and Assembly(创建 CAD 模型和装配)

Create CAD Models and Assembly opens the Create CAD Models dialog window.

Insert Segment List into Drawing(插入分割列表到工程图)

Insert Segment List into Drawing opens the dialog window for inserting a segment list into a CAD drawing.

The list is a table of data that refers back to the part file's custom information section. The table itself does not contain any data except how many segments should be displayed and whether or not to include constant velocity or terminal velocity information. If the part file's custom information is changed the table will be updated automatically.

Edit CAD Models(编辑 CAD 模型)

Edit CAD Models opens the dialog window for editing CAD Models.

Component Template File(零件模板文件)

Component Template File opens a dialog box for specifying the CAD template to be used when creating new CAD models.

Assembly Template File(装配体模板文件)

Assembly Template File opens a dialog box for specifying the CAD template to be used when creating new CAD assemblies.

Fabrication(加工)

Activate Fabrication(激活加工)

Activate Fabrication loads the fabrication settings for the current active path into the property grid.

Process NC File(NC 程序文件)

Process NC File will generate the NC code for the current path using the fabrication properties. The data will be opened using Notepad. The file may be saved to another name or location. Use the Notepad "Save As" command to save to another name or

location. Change the “Save as type” to “All Files”, otherwise the .txt file extension will be added to the file.

Simulate Fabrication(模拟加工)

Simulate Fabrication opens a dialog box that allows CamTrax64 to view an NC file in action.

Save as Default Fabrication Settings(另存为默认加工设置)

Save as Default Fabrication Settings saves the current fabrication settings as the default settings. When a new fabrication is started, these default settings will be used.

Open Default Fabrication Settings(打开默认加工设置)

Open Default Fabrication Settings allows the user to open a previously saved version of the fabrication settings that were saved as the default. This will overwrite the current fabrication settings of the currently active path.

Save Fabrication Settings as(另存为加工设置)

Save Fabrication Settings as allows the user to save the current fabrication setting as a Fabrication file. Fabrication files have the .ctxfab extension.

Open Saved Fabrication Settings(打开已保存的加工设置)

Open Saved Fabrication Settings reads a saved version of the fabrication settings and overwrites the current fabrications settings of the currently active path. Fabrication files have the .ctxfab extension.

View(视图)

Redraw - fit all(重绘-适用所有)

Redraw – fit all redraws the assembly to fit on the screen with the front view and resets the drive position to zero.

Set Drive Angle to 0(设置驱动器角度为 0)

Set Drive Angle to 0 rotates the cam blank back to the starting position.

Show XY Readouts(显示 XY 读数)

Show XY Readouts indicates whether or not the current component information should be displayed in the status strip at the bottom of the CamTrax64 window.

Collapse Grid(折叠网格)

Collapse Grid collapses the property grid to the main paragraphs. The short cut key is F11.

Expand Grid(展开网格)

Expand Grid expands the property grid to display all items. The short cut key is F12.

Toolbars(工具栏)

Standard(标准)

If checked, the Standard tool bar will be displayed. (选择此项, 将会显示标准工具栏)

View(视图)

If checked, the View tool bar will be displayed. (选择此项, 将会显示视图工具栏)

Standard Views(标准视图)

If checked, the Standard Views tool bar will be displayed. (选择此项, 将会显示标准视图工具栏)

Simulation(模拟)

If checked, the Simulation tool bar will be displayed. (选择此项, 将会显示模拟工具栏)

Insert(插入)

If checked, the Insert New Component tool bar will be displayed. (选择此项, 将会显示插入新组件工具栏)

Open Chart Window(打开图标窗口)

Open Chart Window.

Open Machine Layout Window(打开机构设计窗口)

Open Machine Layout Window.

Insert(插入)

Insert New Cylinder into Assembly(插入新圆柱体到装配)

To insert a new cylinder into the assembly:

1. Select Insert from the CamTrax64 menu.
2. Then select Insert New Cylinder into Assembly.

Insert New Cube into Assembly(插入新立方体到装配)

To insert a new cube into the assembly:

1. Select Insert from the CamTrax64 menu.
2. Then select Insert New Cube into Assembly.

Insert New Path into Active Blank(插入新路径到活动毛坯)

Cylinder Surface(圆柱面)

This menu item is enabled if the current active cam blank is a cylinder.

Top Surface(顶面)

This menu item is enabled if the current active cam blank is a cylinder. (如果当时的主凸轮毛坯是一个圆柱体，那么这个菜单项可以启动。)

Bottom Surface(低面)

This menu item is enabled if the current active cam blank is a cylinder.

Upper Surface(上表面)

This menu item is enabled if the current active cam blank is a cube.

Lower Surface(下表面)

This menu item is enabled if the current active cam blank is a cube.

To insert a new path into the active blank: (插入新路径到主毛坯)

Select Insert from the CamTrax64 menu. (在 CamTrax64 菜单中选择“插入”。)

Next select Insert New Path into Active Blank and then select the surface. (接下来选择插入新路径到主毛坯，然后选择表面。)

Insert Segment into Active Path(插入分割到活动路径)

To insert a segment into the active path: (插入一个分割段到主路径)

Select Insert from the CamTrax64 menu. (在 CamTrax64 菜单中选择插入)

Next, select Insert Segment into Active Path. The segment will be inserted after the active segment. (接下来选择插入分割段)

到主路径，这个分割段将会被插入至主分割段后。)

Sample Cams(凸轮样品)

No Dwell(无停歇)

Disk(圆盘型)

This sample disk cam has a single path with two segments. The segments are both harmonic and symmetrical. (圆盘形凸轮样品有一个单独的路径，路径上有 2 个分割段。分割段简谐而对称。)

Cylindrical(圆柱型)

This sample cylindrical cam has a single path with two segments. The segments are both harmonic and symmetrical. (圆柱形凸轮样品有一个单独的路径，路径上有 2 个分割段，分割段简谐而对称。)

Linear(线型)

This sample linear cam has a single path with two segments. The first segment is cycloidal/harmonic and second segment is harmonic/cycloidal. (直线形凸轮样品有一个单独的路径，路径上有 2 个分割段，分割段简谐而对称。)

Single Dwell(单次停歇)

Disk(圆盘)

This sample disk cam has a single path with three segments. The path starts with a cycloidal/harmonic motion then changes to a harmonic/cycloidal motion and finishes with a dwell. The two motions are not symmetrical. The first motion has a beta of 90 degrees and the second motion has a beta of 150 degrees. The symmetry 'n' value has been adjusted for both motions, 2.000 and 0.375 respectively. The helps facilitate a more continuous motion.

Cylindrical(圆柱)

This sample cylindrical cam has a single path with three segments. The path starts with a cycloidal/harmonic motion then changes to a harmonic/cycloidal motion and

finishes with a dwell. The two motions are not symmetrical. The first motion has a beta of 90 degrees and the second motion has a beta of 150 degrees. The symmetry 'n' value has been adjusted for both motions, 2.000 and 0.375 respectively. The helps facilitate a more continuous motion.

Linear(线型)

This sample linear cam has a single path with three segments. The path starts with a cycloidal/harmonic motion then changes to a harmonic/cycloidal motion and finishes with a dwell. The two motions are not symmetrical. The first motion has a beta of 90 degrees and the second motion has a beta of 150 degrees. The symmetry 'n' value has been adjusted for both motions, 2.000 and 1.375 respectively. The helps facilitate a more continuous motion.

Dwell-Rise-Dwell-Return(停歇-升程-停歇-回程)

Disk(圆盘)

This sample disk cam has two cycloidal motions separated by dwells.

Cylindrical(圆柱)

This sample disk cam has two cycloidal motions separated by dwells.

Linear(线型)

This sample disk cam has two cycloidal motions separated by dwells.

Oscillating Arm(摆动臂)

Disk(圆盘)

This sample oscillating arm disk cam has a single path with three segments. The path is single dwell that starts with a cycloidal/harmonic motion rise to a harmonic/cycloidal fall and then finishes with a dwell.

Cylindrical(圆柱)

This sample oscillating arm cylindrical cam has a single path with three segments. The path is single dwell that

starts with a cycloidal/harmonic motion rise to a harmonic/cycloidal fall and then finishes with a dwell.

Linear(线型)

This sample oscillating arm linear cam has a single path with three segments. The path is single dwell that starts with a cycloidal/harmonic motion rise to a harmonic/cycloidal fall and then finishes with a dwell.

Constant Velocity(等速)

Translating(平移)

This sample disk cam has two constant velocity motions that utilize a cycloidal motion to bring the follower to the start of the constant velocity section and then complete with the cycloidal motion.

The first segment has a constant velocity section of 30 degrees and has a displacement of 1.50 inches.

The second segment has a constant velocity section of 90 degrees and has a displacement of -3.21 inches.

Oscillating(摆动)

This sample disk cam has two constant velocity motions that utilize a cycloidal motion to bring the follower to the start of the constant velocity section and then complete with the cycloidal motion.

The first segment has a constant velocity section of 30 degrees of cam rotation and an arm oscillation of 8.27 degrees.

The second segment has a constant velocity section of 60 degrees of cam rotation and an arm oscillation of -13.79 degrees.

Terminal Velocity(终端速度)

Disk(圆盘型)

This sample disk cam has a terminal velocity motion that utilizes a cycloidal motion to bring the follower to the start of the terminal (or constant) velocity section and then completes with the cycloidal motion. The terminal velocity section is for 25 degrees and has a

displacement of 0.25 inches.

Cylindrical(圆柱型)

This sample cylindrical cam has a terminal velocity motion that utilizes a cycloidal motion to bring the follower to the start of the terminal (or constant) velocity section and then completes with the cycloidal motion. The terminal velocity section is for 25 degrees and has a displacement of 0.25 inches.

Linear(线型)

This sample linear cam has a terminal velocity motion that utilizes a cycloidal motion to bring the follower to the start of the terminal (or constant) velocity section and then completes with the cycloidal motion. The terminal velocity section is for 25 degrees and has a displacement of 0.25 inches.

Double Follower(双从动)

Disk(圆盘型)

Translating(平移)

This sample disk cam is a double dwell cam with two translating followers at 2.00" center distance. The path parameters specify an imaginary centerline between the two followers. Each follower is then offset 1.00" from this line.

Oscillating(摆动)

Disk cams with double oscillating followers are not available. Use the conjugate option.

Cylindrical(圆柱型)

Translating(平移)

This sample cylindrical cam is a double dwell cam with two translating followers at 2.00" center

distance. The path parameters specify an imaginary centerline between the two followers. Each follower is then offset 1.00" from this line.

Oscillating(摆动)

This sample cylindrical cam is a double dwell cam with two oscillating followers at 2.00" center distance. The path parameters specify an imaginary centerline between the two followers. Each follower is then offset 1.00" from this line. The distance between each follower and the pivot equals the

arm length.

Tools(工具)

Copy Hub Top Side(复制轮毂顶端)

Copy Hub First Side copies the hub first side data to the copy hub clipboard for pasting to the second side hub or to either side of other components.

Copy Hub Bottom Side(复制轮毂底端)

Copy Hub Second Side copies the hub second side data to the copy hub clipboard for pasting to the first side hub or to either side of other components.

Paste to Hub Top Side(粘贴到轮毂顶端)

Paste to Hub First Side pastes the data stored in the hub copy clipboard to the hub first side of the current active component.

Paste to Hub Bottom Side(粘贴段轮毂底端)

Paste to Hub Second Side pastes the data stored in the hub copy clipboard to the hub second side of the current active component.

Swap Hub Sides(互换轮毂边)

Swap Hub Sides swaps the hub data of the two sides for the current active component.

Animation Speed(动画速度)

Animation Speed sets the animation speed for the simulation. The slower the speed the finer the angular steps in the simulation. Select between Very Fast, Fast, Medium, Slow and Very Slow.

Reverse Animation Direction(方向动画方向)

To reverse the direction of the animation, place a check in front of the Reverse Animation Direction menu item.

Create Data Sheet(创建数据表)

A data sheet of the currently active cam path segments may be created in an Excel or text file format.

CamBlankCylinder1.txt - Notepad

File Edit Format View Help

File Location: C:\Users\grh\Documents\CamTrax64 Tests\CamBlankCylinder1.txt
Date: Friday, December 26, 2008
Time: 1:22:56 PM

----- CamTrax64 -----

CAM DIRECTION: CLOCKWISE
PATH TYPE: POSITIVE
FOLLOWER DIAMETER: 1-1/4
FOLLOWER SPECIFICATION: TRANSLATING
PATH CLEARANCE: 0.0050in
PATH DEPTH: 0.8750in
CYCLE TIME (sec): 1
RPM: 60.0
FOLLOWER CONTACT WIDTH: 0.5000in
MODULUS OF ELASTICITY: 30x10⁶
WEIGHT OF ACCELERATED ELEMENTS: 10.0lb
EXTERNAL FORCES: 0.0lb
SPRING RATING: 0.0000lb/in
SPRING COMPRESSION START AT: 0.2500in
SPRING COMPRESSES WITH CAM RISE
COEFFICIENT OF FRICTION: 0.020

START ANGLE	END ANGLE	START OFFSET	END OFFSET	SYMMETRY FACTOR	MOTION TYPE
0.0deg	90.0deg	2.0000in	5.0000in	1.000	Cycloidal_Harmonic
90.0deg	180.0deg	5.0000in	2.0000in	1.000	Harmonic_Cycloidal
180.0deg	360.0deg	2.0000in	5.0000in	1.000	Dwell

CAM ROTATION ANGLE	FOLLOWER POSITION BETA	VELOCITY in/sec	ACCELER- ATION in/sec ²	PRESSURE ANGLE PHI2	TORQUE T	NORMAL FORCE F _N	RADIUS OF CURVATURE R _C	CONTACT STRESS S _C	PULSE P
0.0	2.0000	0.00	0.0	0.0	0.0	10.0	4.267	4454.5	6668.8
1.0	2.0000	0.03	38.5	0.1	0.0	10.5	4.267	4560.0	6652.5
2.0	2.0002	0.10	38.9	0.5	0.2	11.0	2.138	5120.2	6601.9
3.0	2.0006	0.23	55.2	1.1	0.4	13.4	1.433	5858.3	6523.0
4.0	2.0015	0.41	73.1	1.9	0.8	13.9	1.085	6892.7	6410.4
5.0	2.0030	0.64	90.8	2.9	1.3	12.4	0.881	8484.0	6266.6
6.0	2.0051	0.91	107.9	4.1	1.9	12.8	0.751	11383.5	6090.2
7.0	2.0081	1.24	124.6	5.6	2.6	13.3	0.663	19677.3	5888.2
8.0	2.0120	1.60	140.6	7.2	3.5	13.7	0.605	26291.9	5655.4
9.0	2.0170	2.02	156.0	9.0	4.5	14.2	0.566	35205.5	5395.1
10.0	2.0232	2.47	170.6	11.0	5.6	14.6	0.544	42861.4	5108.6
11.0	2.0308	2.96	184.3	13.1	6.9	15.1	0.534	42262.7	4797.1

Sample of a data sheet created as text file

Create XY File(创建 XY 文件)

An XY file can be created for disk and linear cam paths. The file format may be an Excel, text or DXF File.

Open install folder using Explorer(使用资源管理器打开安装目录)

Open install folder using Explorer opens the folder where CamTrax64 is installed using Windows Explorer.

Options(选项)

Options loads the CamTrax64 options into the property grid on the left side of the CamTrax64 window.

Help (帮助)

CamTrax64 Help Topics(CamTrax64 在线帮助主题)

CamTrax64 Help Topics starts the CamTrax64 help system.

CamTrax64 Help for CAD(CamTrax64 的 CAD 帮助)

CamTrax64 Help for CAD starts the help system for your specific CAD system.

CamTrax64 Manual (PDF) (CamTrax64 手册)

CamTrax64 Manual (PDF) opens the manual file. The Adobe Reader must be loaded on the computer.

CamTrax64 Quick Start Guide (PDF)(CamTrax64 快速入门指南)

CamTrax64 Quick Start Guide opens the quick start file. The Adobe Reader must be loaded on the computer.

Registration (注册)

Registration loads the registration properties in the property grid. Starting a new component or selecting a component from the component selector will close the registration properties.

Create an Email with registration information(创建带有注册信息的电子邮件)

Create an Email with registration information loads the registration properties in the property grid and starts a new email using the default email program. Starting a new component or selecting a component from the component selector will close the registration properties.

View License Agreement(查看许可协议)

View License Agreement opens the license agreement in Notepad.

Check for Updates(检查更新)


Check for Updates accesses the Camnetics, Inc. web site for a newer version of CamTrax64. The Internet must be available.

About CamTrax64 (关于)

About CamTrax64 opens a dialog box that has some general information about Camnetics, Inc. and CamTrax64.

Options (选项)

The Options settings are made available through the CamTrax64 menu item Tools>Options. The Options are displayed in the property grid when CamTrax64 is started.



Color and Line Options(颜色和线条选项)

Color Back Ground(背景颜色)

Color Back Ground defines the color to be used as the background on the GearTrax64 drawing window. This value is saved as a default for the next time CamTrax64 is started.

Color Cam Follower(从动凸轮颜色)

Color Cam Follower defines the color to be used for displaying the cam follower in the display window. This value is saved as a default for the next time CamTrax64 is started.

Color Intensity Cam Follower(从动凸轮颜色强度)

Color Intensity Cam Follower defines the intensity of the color used to display the cam follower in the CamTrax64 window. This value is saved as a default for the next time CamTrax64 is started.

Image Quality(图像质量)

Image Quality defines the quality of the components that are display in the CamTrax64 window. This value is saved as a default for the next time CamTrax64 is started.

Line Weight(线宽)

Line Weight defines the thickness of the lines used to draw the components in the CamTrax64 window. This value is saved as a default for the next time CamTrax64 is started.

Shaded Display Near Side(着色显示边线)

Shaded Display Near Side defines the intensity of shading, if any, on the near side surface of the components in the CamTrax64 window. This value is saved as a default for the next time CamTrax64 is started.

Show Path Lines(显示路径线)

Show Path Lines. This value is saved as a default for the next time CamTrax64 is started.

General Options(常规选项)**Animation Speed(动画速度)**

Animation speed sets the animation speed for the simulation. Slower speed settings will produce finer steps in the simulation. Select between Very Fast, Fast, Medium, Slow and Very Slow. This value is saved as a default for the next time CamTrax64 is started.

Collapse Grid on Startup(启动时折叠网格)

Collapse Grid on Startup defines whether the property grid should be collapsed on startup. This value is saved as a default for the next time CamTrax64 is started.

Decimal Places(小数位数)

Decimal Places determines the number of decimal places from normal. The normal setting is x.xxxx for inches and x.xxx for millimeters. This option will not change the standard or add one or two decimal places to most of the values displayed or presented in any data sheets. This may not affect some settings.

Default Units(默认单位)

Default Units defines the units (inches or millimeters) to be used when creating a new CamTrax64 component. This value is saved as a default for the next time CamTrax64 is started.

Fabrication File Extension Name(加工文件扩展名)

The default extension name for fabrication files is "NC". The user may change the file extension name but it must be at least 2 characters and not exceed 6 characters.

Grid Font(网格字体)

Grid Font defines the font for the property and segment grid. The font

is saved as a default for the next time CamTrax64 is started.

Mouse Drag Speed(鼠标拖动速度)

Mouse Drag Speed defines the impact of mouse movements in conjunction with the Drive and Rotate the View toolbar controls. This value is saved as a default for the next time CamTrax64 is started.

Mouse Wheel Direction(鼠标滚轮方向)

Mouse Wheel Direction determines the zoom direction when zooming in or out in the CamTrax64 display window. This value is saved as a default for the next time CamTrax64 is started.

Show XY Readout(显示 XY 读数)

Show XY Readout defines if the XY readout will be displayed in the status bar at the bottom of the CamTrax64 window. This value is saved as a default for the next time CamTrax64 is started.

Spin Increment(旋转增量)

Spin Increments defines the angle of increment when clicking on the simulation toolbar's forward and back buttons. Integers between 1 and 30 are valid. This value is saved as a default for the next time CamTrax64 is started.

New Version Options(新的版本选项)

New Version Check on Startup(启动时检查新版本)

New Version Check on Startup defines if CamTrax64 should check if a newer version is available on the web site. This value is saved as a default for the next time CamTrax64 is started. Access to the Internet is a must for this option to function.

New Version is Available(可用新版本)

New Version is Available is a read only property that states if a newer version is available on www.camnetics.com. Access to the Internet is a must for this option to function.

Oscillating Cam Options(摆动凸轮输出)

Oscillating Cam Output(摆动凸轮输出)

The Oscillating Cam Output allows the user to select between: Follower, as linear distance from the origin plane. Arm Angle in Degrees from the common angle*.

Arm angle in Radians from the common angle*. Reaction Arm (arc distance).

* The common angle is a line from the cam origin to the pivot point of the oscillating arm.

Settings, CAD(CAD 设置)

CAD Version(CAD 版本)

CAD Version defines which version of CAD to use with CamTrax64 when it is running as an Add-On. This option is not available when CamTrax64 is running as an Add-In. This value is saved as a default for the next time CamTrax64 is started.

Display Annotations in Upper Case(以大写形式显示注解)

Display Annotations in Upper Case determines if annotations created in CAD are all upper case or a mix of case. This value is saved as a default for the next time CamTrax64 is started.

Template File for Assembly(零件文件模板)

Template File for Assembly displays the template file to be used when creating a new assembly document in CAD. This is a read- only value. Set the location and name of the template file in the CamTrax64 menu item CAD>Assembly Template File... This value is saved as a default for the next time CamTrax64 is started.

Template File for Component(装配体模板文件)

Template File for Component displays the template file to be used when creating a new part document in CAD. This is a read-only value. Set the location and name of the template file in the CamTrax64 menu item CAD>Component Template File... This value is saved as a default for the next time CamTrax64 is started.

Cam Blank Cylinder(圆柱凸轮毛坯)

Cam Blank Cylinder is a base object that cam paths are cut into. Cylindrical and disk type cam paths may be added to a cylinder. Cylindrical cam paths are added to the curved surface of the cylinder. Disk cam paths are added to either end of the cylinder.

Cam Blank Data (Cylinder)(凸轮毛坯数据)(圆柱型)

AXIS(轴)

Axis allows the user to select the axis for the cam center. Select X, Y or Z.

Blank Chamfer(毛坯倒角)

Blank Chamfer defines the size of the chamfer for the edges of the cam blank.

Blank Diameter(毛坯直径)

Blank Diameter defines the size of the blank diameter.

Blank Height(毛坯高度)

Blank Height defines the size of the blank height.

Color Cam Blank(凸轮毛坯颜色)

Color Cam Blank allows the user to select the display color for the cam blank.

Name Cam Blank(凸轮毛坯名称)

Name Cam Blank defines the name of the cam.

Path File(文件路径)

Path File is read only and is determined when the cam blank is saved.

Units(单位)

Units provides a method for the user to select between Inches or Metric units for the cam blank.

Cam Rotation(凸轮旋转)

Cycle Time(循环时间)

Cycle Time defines the amount of time in seconds for the cam blank to make one full revolution.

$$\text{Cycle Time} = 60 / \text{RPM}$$

Direction Rotation(旋转方向)

Direction Rotation provides a method for the user to change the rotation direction of the cam. The user may select Clockwise or Counter Clockwise.

RPM(转速)

RPM defines the frequency of rotation of the cam blank. $RPM = 60 / \text{Cycle Time}$

Cam Position(凸轮位置)**X Delta(X 增量)**

X Delta defines the distance between the origin of the cam blank and the origin of the assembly on the X axis.

Y Delta(Y 增量)

Y Delta defines the distance between the origin of the cam blank and the origin of the assembly on the Y axis.

Z Delta(Z 增量)

Z Delta defines the distance between the origin of the cam blank and the origin of the assembly on the Z axis.

Hub Data(轮毂数据)**Bore Chamfer(孔倒角)**

Bore Chamfer defines the size of the chamfer at the ends of the bore.

Bore Diameter(孔直径)

Bore Diameter defines the diameter of the bore.

Hub Bottom Side Chamfer(轮毂底边倒角)

Hub Bottom Side Chamfer defines the size of the chamfer and fillet for the hub revolve on the bottom of the cylinder.

Hub Bottom Side Diameter(轮毂底边直径)

Hub Bottom Side Diameter defines the size of the diameter of the hub revolve on the bottom of the cylinder.

Hub Bottom Side Projection(轮毂底边长度)

Hub Bottom Side Diameter defines the size of the projection of the hub revolve on the bottom of the cylinder.

Hub Top Side Chamfer(轮毂顶边倒角)

Hub Top Side Chamfer defines the size of the chamfer and fillet for

the hub revolve on the top of the cylinder.

Hub Top Side Diameter(轮毂顶边直径)

Hub Top Side Diameter defines the size of the diameter of the hub revolve on the top of the cylinder.

Hub Top Side Projection(轮毂顶边长度)

Hub Top Side Projection defines the size of the projection of the hub revolve on the top of the cylinder.

Keyway(键槽)

Keyway defines the type of keyway, if any, to be created with the component. A valid bore diameter must be specified.

Keyway Angle(键槽角度)

Keyway Angle defines the keyway relative to the 0 position.

Mounting Bushing Modeling(安装衬套建模)

Mounting Bushing Modeling determines if the bushing should be created as part of the component or as a new part. Select 'Create as component feature' to have the bushing created as a feature in the CAD model. Select 'Create as new part' to have the bushing created as a new CAD model.

Mounting Bushing Side(安装衬套边)

Mounting Bushing Side defines on which side of the component the bushing will be mounted.

Mounting Split Taper Bushing(安装分裂锥形衬套)

Mounting Split Taper Bushing defines, if any, the bushing to be used with the component.

Standard Set Screw(标准紧定螺钉)

Standard Set Screw defines if a standard set screw should be used with a keyway. The setscrew hole will only be created if a hub and keyway are also created.

Cam Blank Cube(立方体凸轮毛坯)

Cam Blank Cube is a base object that is used to cut cam paths. Linear cam paths are the only type of cam path that can be added to the cube. Linear cam paths are added to either the upper or lower surface of the cube.

Cam Blank Data (Cube)(凸轮毛坯)(立方体)

AXIS(轴)

Axis allows the user to select the axis for the cam blank thickness value. Select X, Y or Z.

Blank Length(毛坯长度)

Blank Length defines the size of the blank length. The blank length is used for the direction of the cam path angle.

Blank Thickness(毛坯厚度)

Blank Thickness defines the size of the blank thickness.

Blank Width(毛坯宽度)

Blank Width defines the size of the blank width. The blank width is used for the direction of the cam path displacement.

Cam Paths(凸轮路径)

Cam Paths are grooves cut into a cam blank. A cam path is made up of one or more cam segments.

Cam Blank Data(凸轮毛坯日期)

Cam Blank Name(凸轮毛坯名称)

Cam Blank Name is a drop down box that allows the user to select the which cam blank is used with the path. A cam path must have a cam blank specified. If "none" is specified, the cam path will not be displayed on the screen or created in CAD.

Units(单位)

Units provides a method for the user to select between Inches or Metric units for the cam path. Each path may have its own unit setting that is different from the cam blank's unit setting. CamTrax64 may set the path units to match the cam blank unit setting while the cam is being created in CAD.

Path Specifics(路径细节)

Name Path(路径名称)

Name Path is the name of the current path, which will be used to name

path features when they are created in CAD.

Number of Segments(分割数)

Number of Segments is a read only value, which displays the number of motion segments in the current active path.

Path Closed(路径关闭)

With Path Closed set to true CamTrax64 will change the start of the first segment to match the end of the last segment when it is changed. Likewise for the end of the last segment, if the start of the first segment is changed. The cam will have 360 degrees rotation. If the start angle of the first segment is changed to 20 degrees then the end of the last segment will be changed to 380 degrees.

Path Segments Continuous(连续分割路径)


With Path Segments Continuous set to true CamTrax64 will automatically change the start of the next segment if the current segment end is changed. Likewise if the start of the current segment is changed then the end of the preceding segment will automatically be changed.

Path Surface(路径表面)


Path surface is used to select which surface the path is on. For cylinder blanks the options are Cylinder, Top and Bottom. For cube blanks the options are upper and lower.

Path Type(路径类型)


Path Type is used to select the type of path. For paths on the cylinder surface the options are Positive, Upper and Lower. For paths on the Top or Bottom surface of a cylinder blank the options are Positive, Inside, Outside and Inside Surface Only.




Inside Surface Only Path Type on a Top Surface




Positive Path Type on a Top Surface




Inside Path Type on a Top Surface




Outside Path Type on a Top Surface



Positive Path Type on a Cylinder Surface



Upper Path Type on a Cylinder Surface



Lower Path Type on a Cylinder Surface

Follower Data(从动数据)


Crowned Follower(鼓形从动)

Select between true or false. Crowned followers should always be used for paths on the cylinder.


Dual Follower Separation(双从动分离)

If a value is entered into the Dual Follower Separation property then the positive cam path is created with a ribbon that is encapsulated by two followers. The value for the Dual Follower Separation must be at least 10% greater than the diameter of the follower.


Both followers are of the same diameter.



Dual Follower on the Top Surface of a Linear Translating Disk Cam



Dual Follower on the Cylinder Surface of a Linear Translating Barrel Cam



Dual Follower on the Cylinder Surface of an Oscillating Barrel Cam

Follower Size Dimensional(从动尺寸)


Follower Size Dimensional allows the user to enter a specific size follower that may or may not be a common size.

Follower Size Nominal(从动公称尺寸)


Follower Size Nominal allows the user to select from a list of common imperial and metric size followers. Use the Follower Size Dimensional property to enter a specific follower size.

Follower Type(从动类型)

Follower Type allows the user to select between Translating and Oscillating follower types.



Translating Follower on a Disk Cam with a Positive Path



Oscillating Follower on a Disk Cam with a Positive Path

Heavy Stud(重型螺栓)

The Heavy Stud property allows the user to select between true or false. Set to true for a heavy stud and false for a standard stud on the cam follower.

Path Clearance(路径间隙)

Path Clearance defines the amount of clearance between the follower diameter and the path width. Setting the clearance to 0.005in on a 1.250in diameter follower will create a cam path width of 1.255in.

Path Depth(路径深度)

The Path Depth property defines how deep the cam path will be cut into the cam blank.

Translating offset(平移偏移量)

The Translating Offset property defines how far the cam follower is offset in a positive or negative direction for translating followers. Normally this value should be 0.000 as there is very little reason to ever develop a cam with an offset.


Oscillating Arm Data(摆动臂数据)

Arm Length(臂长度)


Arm Length is a linear distance between the pivot point and the follower center.

Flip Quadrant(翻转象限)

Flip Quadrant moves the arm to the other side of the line between the cam center and the pivot point (sometimes called the common angle). This is only valid for disk cams with an oscillating follower type.



Flip Quadrant set to False



Flip Quadrant set to True

Pivot X(X 枢轴)

Pivot X defines the distance of the pivot point from the cam center in the X direction.

Pivot Y(Y 枢轴)

Pivot Y defines the distance of the pivot point from the cam center in the Y direction.

Reaction Arm Length(反应臂长度)

Reaction Arm Length is the length of an imaginary line that extends from the pivot point and oscillates with the follower arm. This is valid for oscillating follower types only.

Conjugate Data(共轭数据)

The Conjugate Data properties are used to convert the active cam path to a conjugate path. Start the conversion of a standard path into a conjugate by selecting the Conjugate Master Cam Path. Then define the other valid properties to complete the conversion.

Conjugate Follower Angle(共轭从动角度)

Conjugate Follower Angle defines the angle between two lines extending from the pivot point to each of the cam follower centers. This is only valid if the master cam path is an oscillating follower type.

Conjugate Follower Center Distance(共轭从动中心距离)

Conjugate Follower Center Distance defines the distance between the two followers of a conjugate cam. A good starting dimension will be the least offset plus the greatest offset of the master cam path. This is only valid if the master cam path is a translating follower type.

Conjugate Master Cam Path(共轭主凸轮路径)

Conjugate Master Cam Path defines which path is to be used as a master path.

Load Data(加载数据)**Contact Width(接触宽度)**

Contact Width defines the amount of contact between the follower face and the cam path surface. Normally this is the full width of

the cam follower unless the follower does not fully extend into the cam path.

External Forces(外力)

External Forces define any external force that will be applied to the follower. A good example of this type of force would be an air spring where there is very little mass relative to the amount of force generated.

Friction Coefficient(摩擦系数)

Friction Coefficient defines the coefficient of friction for any sliding device attached to the follower.

Modulus of Elasticity Follower(从动弹性模量)

Modulus of Elasticity Follower defines the value for the modulus of elasticity for the cam follower. Entering 25 into the property will result in a 25×10^6 value.

Modulus of Elasticity Path(路径弹性模量)

Modulus of Elasticity Path defines the value for the modulus of elasticity for the cam path. Entering 25 into the property will result in a 25×10^6 value.

Spring Compresses(弹簧压缩)

Spring Compresses allows the user to switch between "With Cam Rise" and "With Cam Fall" options. If "With Cam Rise" is selected then when the follower is rising (moving away from the center of a disk cam or the base of a cylindrical cam) the spring will be compressing according to the amount of rise.

Spring Compression at Cam Zero(凸轮弹簧压缩零)

Spring Compression at Cam Zero defines the linear amount of spring compression for the follower position at the start of the first cam path segment.

Spring Rating(弹簧等级)

Spring Rating defines the strength of the spring. For a cam with inch units the rating is pounds per inch (lb/in) and for metric cams the rating is kilograms per meter (kg/m).

Weight of Accelerated Elements(加速元素重量)

Weight of Accelerated Elements defines the mass of all objects that are attached to the cam follower.

Cam Segments(凸轮分割)

Cam Segments are parts of a cam path. A cam path is made up of one or more cam segments. Properties of Cam Segments are displayed above the graphic window.

Start Angle(开始角度)

Start Angle is the cam angle at the start of the segment.

End Angle(结束角度)

End Angle is the cam angle at the end of the segment.

Start Offset(开始偏移量)

For disk cam paths:

Start Offset is the distance between the center of the follower at the start of a segment and the center of the cam.

For cylindrical cam paths:

Start Offset is the distance between the center of the follower at the start of a cam path segment and the cam origin plane.

For linear cam paths:

Start Offset is the distance between the center of the follower at the start of a cam path segment and the cam origin plane.

End Offset(结束偏移量)

For disk cam paths:

End Offset is the distance between the center of the follower at the end of a segment and the center of the cam.

For cylindrical cam paths:

End Offset is the distance between the center of the follower at the end of a cam path segment and the cam origin plane.

For linear cam paths:

End Offset is the distance between the center of the follower at the end of a cam path segment and the cam origin plane.

Start Arm Angle(开始臂角度)

For disk cam paths:

Start Arm Angle is the angle between the arm and the common angle line at the start of the segment. The common angle line is a line that extends from the center of the cam to the pivot point of the oscillating arm.

For cylindrical cam paths:

Start Arm Angle is the angle between the arm and a line that extends from the center of the pivot and is parallel to the origin plane, at the start of the cam path segment.

End Arm Angle(结束臂角度)

For disk cam paths:

End Arm Angle is the angle between the arm and the common angle line at the end of the segment. This property is only valid for oscillating disk cam paths. The common angle line is a line that extends from the center of the cam to the pivot point of the oscillating arm.

For cylindrical cam paths:

End Arm Angle is the angle between the arm and a line that extends from the center of the pivot and is parallel to the origin plane, at the end of the cam path segment.

Motion Type(运动类型)

Motion Type allows the user to select between most common types of cam motions.

Configure(配置)

Configure allows the user to make further adjustments to the parameters of the segment. For example, the symmetry 'n' value may be adjusted for a cycloidal motion.

Precision(精度)



Precision allows the user to select between 0.1, 0.2, 0.5, 1.0 and 2.0 degrees. This determines how often a point (at the center of the path) will be created to define the spline that creates the cam path segment.

Color(颜色)

Color allows the user to select between a limited number of colors to be used to display each cam segment in the display area.

Oscillating Followers(摆动从动)


The Arm Angle of a cylindrical cam path is from perpendicular of the cam axis to the pivot point to the center of the follower. The Offset is a linear dimension between the cam base and the follower center. The Arm Angle of a disk cam is from the cam center to pivot point and to the follower center. The Offset is a linear dimension between the cam center and the follower center.



Segment Configuration(分割配置)

The Segment Configuration window varies with the type of motion used in that

segment. The configuration properties below are valid for cycloidal, harmonic, modified sine, modified trapezoid, cycloidal/harmonic and harmonic/cycloidal motions.



Configuration(表面配置)

Start Angle is the cam angle at the start of the segment.

beta

beta is the angle of cam rotation for this segment of the cam path.

h

h is the total displacement for this segment of the cam path.

h1

h1 is the amount of acceleration displacement for this segment of the cam path.

$$h1 = h / (1 + n)$$

h2

h2 is the amount of deceleration displacement for this segment of the cam path.

$$h2 = h - h1$$

n

Symmetry factor n. If n = 1.0 then the segment will be symmetrical.

theta 1

theta1 is the amount of acceleration angle (cam) for this segment of the cam path.

$$theta1 = beta / (1 + n)$$

theta 2

theta1 is the amount of deceleration angle (cam) for this segment of the cam path.

$$\text{theta2} = \text{beta} - \text{theta1}$$

Maximum Velocity and Accelerations(最大速度和加速度)

The maximum velocity and accelerations are displayed in the property grid for the current segment. These values are read only and are calculated using the parameters of the cam path segment.

Max Negative Acceleration(最大负加速度)

a.

Max Positive Acceleration(最大正加速度)

a.

Max Velocity(最大速度)

a.

Truncation(舍去)

Truncation provides a method to shorten the cam segment without changing the cam parameters. This provides the designer with the ability to combine any cam motion with another cam motion. The Path Segments Continuous property of the cam path must be set to false to overlap (and combine) segments.

End Truncation by Angle(结束截断的角度)

End Truncation by Angle defines the amount of degree that the cam segment should be shortened at the end of the segment.

Start Truncation by Angle(开始截断的角度)

Start Truncation by Angle defines the amount of degree that the cam segment should be shortened at the start of the segment.

Buttons(按钮)

Print(打印)

Pressing the Print button will open a print dialog window that will allow the user to send the Segment Configuration graphics to the default printer.

Cancel(取消)

Pressing the Cancel button will restore the original setting and close the window.

Apply(应用)


Pressing the Apply button will force the CamTrax64 display window to update with the new settings.

OK(确定)

Pressing the OK button will save the settings, update the CamTrax64 display window and close the configuration dialog window.

Configure Constant Velocity(等速配置)

Pressing the Edit button in the segment grid line of a Constant Velocity (CV) motion will open the Configure Constant Velocity Window.



The constant velocity section is always after the acceleration portion of the segment and before the deceleration portion. If you would like the constant velocity section to be within the acceleration or deceleration portion (for example, for a press operation) then consider using the terminal velocity motion type.

Tip: If you are laying out a cam that requires a specific velocity for the constant velocity during a certain period of time, start by centering the cam segment on the center of the desired layout. Then specify the velocity for the CV portion of the segment. Then change the amount of displacement and/or angle for the segment until the segment provides enough displacement at the constant velocity.

Cycle Data(周期数据)

Cycle Time(循环时间)

Cycle Time is the amount of time required for one revolution of the cam or 360 degrees of a linear cam. This value is read only.

Segment Angle(分割角度)

Segment Angle is the amount of angle in degrees for the complete terminal segment. This value is read only.

Segment Displacement(分割移位)

Segment Displacement is the amount of linear displacement for the complete terminal velocity segment. This value is read only.

Segment Time(分割时间)

Segment Time is the amount of time in seconds required to complete the entire terminal velocity segment. This value is read only.

Constant Velocity Parameters(等速度参数)**Accel Decel Type(加速减速类型)**

Accel Decel Type (acceleration/deceleration type) provides a method for the designer to switch between a number of different motion types to be used to control the acceleration before the constant velocity and the deceleration after the constant velocity portion of the motion.

Displacement of CV(等速度位移)

Displacement of CV (constant velocity) provides a method for the designer to input the amount of displacement for the segment that will be at a constant velocity. Because of the laws of cam motions, velocity and the start and end positions of the constant velocity may change.

Velocity of CV(等速度速度)

Velocity of CV (constant velocity) provides a method for the designer to input the velocity of the segment that will be at a constant velocity. Because of the laws of cam motions, displacement and the start and end positions of the constant velocity may change.

Angle of CV(等速度角度)

Angle of CV (constant velocity) provides a method for the designer to input the amount of cam angle during the constant velocity. Because of the laws of cam motions, velocity, displacement and the start and end positions of the constant velocity may change.

Time of CV(等速度时间)

Time of CV (constant velocity) provides a method for the designer to input the amount of time for the duration of the constant velocity. Because of the laws of cam motions, velocity, displacement and the start and end positions of the constant velocity may change.

Minimum Velocity Allowed(最小允许速率)

Minimum Velocity Allowed is a read only display of the minimum velocity allowed according to the specifications of the cam segment. If the Velocity of CV is changed, it must be equal to or greater than this value.

Maximum Velocity Allowed(最大允许速率)

Maximum Velocity Allowed is a read only display of the maximum velocity allowed according to the specifications of the cam segment. If the Velocity of CV is changed, it must be equal to or less than this value.

Symmetry(对称)

Symmetry(对称)

Symmetry allows the designer to create a constant velocity section that is asymmetrical. Select between Symmetrical and Asymmetrical modes.

An asymmetrical constant velocity motion can have a different amount of acceleration than deceleration. For example, the acceleration may happen over 20 degrees of cam motion but the deceleration over 30 degrees of cam motion.

The other items in this Symmetry paragraph are read only unless this property is set to Asymmetrical.

Acceleration Displacement(加速度位移)

Symmetrical mode:

The Acceleration Displacement property is read only and displays the calculated displacement for the acceleration portion of the segment.

Asymmetrical mode: ()

The Acceleration Displacement property allows the designer to specify a set amount of displacement for the acceleration portion of the segment.

Acceleration Angle(加速度角度)

Symmetrical mode:

The Acceleration Angle property is read only and displays the calculated cam angle used for the acceleration portion of the segment.

Asymmetrical mode:

The Acceleration Angle property allows the designer to specify a set amount of cam angle used for the acceleration portion of the segment.

Deceleration Displacement(加速度位移)

Symmetrical mode:

The Deceleration Displacement property is read only and displays the calculated displacement for the deceleration portion of the segment.

Asymmetrical mode:

The Deceleration Displacement property allows the designer to specify a set amount of displacement for the deceleration portion of the segment.

Deceleration Angle(减速度角度)

Symmetrical mode:

The Deceleration Angle property is read only and displays the calculated cam angle used for the deceleration portion of the segment.

Asymmetrical mode:

The Deceleration Angle property allows the designer to specify a set amount of cam angle used for the deceleration portion of the segment.

Buttons and Slider Bar(按钮和滑块)

Chart Type (drop down selector)(图表类型(下拉选择器))

The Chart Type drop down selector allows the user to switch between different chart types. The default is displacement. The graphics window can also display velocity, acceleration, pressure angle, torque, normal force, radius of curvature, contact stress and pulse (or jerk).

The text box below the drop down selector displays data for the current slider position.

Cancel(取消)

Pressing the Cancel button will restore the origin setting and close the window.

Restore(还原)

Pressing the Restore button will delete any changes made to the configuration since the window was last opened.

OK(确定)

Pressing the OK button will save the settings, update the CamTrax64 display window and close the configuration dialog window.


Slider Bar(滑块)

The Slider Bar provides a method for the designer to analyze the

characteristics of the curve at any given position. Drag the bar left or right and the text box will display the current angle and the value for the type selected in the Chart Type selector.

Configure Terminal Velocity()

Pressing the Edit button in the segment grid line of a Terminal Velocity (TV) motion will open the Configure Terminal Velocity Window.



Cycle Data()

Cycle Time(循环时间)

Cycle Time is the amount of time required for one revolution of the cam or 360 degrees of a linear cam. This value is read only.

Segment Angle(分割角)

Segment Angle is the amount of angle in degrees for the complete terminal segment. This value is read only.

Segment Displacement(分割位移)

Segment Displacement is the amount of linear displacement for the complete terminal velocity segment. This value is read only.

Segment Time(分割时间)

The segment time is the amount of time in seconds required to complete the entire terminal velocity segment. This value is read only.

Configure(配置)

TV Start Offset(终端速度开始偏移)

TV Start Offset is a linear value of the amount of displacement at the beginning of the segment before the start of the constant velocity portion of the segment. This displacement will be acceleration and will include deceleration if the terminal location is at the end of the segment. This value will change with the type of motion selected. This value is read only.

TV Start Angle(终端速度开始角度)

TV Start Angle is an angular value in degrees for the amount of cam angle at the beginning of the segment before the start of the constant velocity portion of the segment. This displacement will be acceleration and will include deceleration if the terminal location is at the end of the segment. This value will change with the type of motion selected. This value is read only.

TV End Offset(终端速度终止偏移)

TV End Offset is a linear value of the amount of displacement at the end of the segment after the end of the constant velocity portion of the segment. This displacement will be deceleration and will include acceleration if the terminal location is at the start of the segment. This value will change with the type of motion selected. This value is read only.

TV End Angle(终端速度终止角度)

TV End Angle is an angular value in degrees of the amount of cam angle at the end of the segment after the end of the constant velocity portion of the segment. This displacement will be deceleration and will include acceleration if the terminal location is at the start of the segment. This value will change with the type of motion selected. This value is read only.

Terminal Velocity Parameters(终端速度配置)

Motion Type(运动类型)

Motion Type determines the type of motion to be used in conjunction with the constant velocity to create a terminal type of motion.

Terminal Location(终端位置)

Terminal Location determines if the constant velocity portion will be at the start or end of the segment.

Displacement of TV(终端速度位移)

Displacement at TV sets the amount of displacement that will be at a constant velocity. Changing this value will also change the Velocity of TV value.

Velocity of TV(终端速度速度)

Velocity of TV sets the velocity for the constant velocity portion of the segment. Changing this value will also change the Displacement of TV value.

Time of TV(终端速度时间)

Time of TV determines how long the constant velocity portion of the segment will be in seconds. Changing this value will also change the Velocity of TV and the Angle of TV. The Displacement of TV will remain unchanged.

Angle of TV(终端速度角度)


Angle of TV determines the amount of cam angle that will be used for the constant velocity portion of the segment. Changing this value will also change the Velocity of TV and the Angle of TV. The Displacement of TV will remain unchanged.

Pass Fail(通过失败)

Pass-Fail is a read only value that indicates if the set of values makes a valid terminal velocity motion.

Configure User Points(配置用户点)

Pressing the Edit button in the segment grid line of a User Points motion will open the Configure User Points window.



Data Area(数据区)

The Data Area contains the user entered points. A single column of

data may be entered (copy and paste recommended) into this area. CamTrax64 will convert a single column of offsets to a double column of cam segment angles and offsets.

Apply(应用)

Apply will force the CamTrax64 display window to update with the new settings.

Cancel(关闭)

Cancel will restore the original setting and close the window.

OK(确定)

OK will save the settings, update the CamTrax64 display window and close the configuration dialog window.

Motion Types(运动类型)

Motion Types define the type of motion that is used for a single cam path segment. Each motion has its own characteristics.

Dwell(停歇)

A Dwell has no change in displacement or velocity. The end offset always equals the start offset.

Cycloidal(摆线)

Cycloidal motions have smooth starts and ends. The acceleration rates at the start and end are 0.000. The cycloidal motion is an acceptable motion to use between two dwells.

$$\text{Displacement: } s = h \left[\frac{\theta}{\beta} - \frac{\sin 2\pi(\theta/\beta)}{2\pi} \right]$$

$$\text{Velocity: } v = h \left[\frac{1 - \cos 2\pi(\theta/\beta)}{T} \right]$$

$$\text{Acceleration: } a = h \left[\frac{2\pi \sin 2\pi(\theta/\beta)}{T^2} \right]$$

The value for n may be configured, which alters where the acceleration rate changes from positive to negative during the duration of the motion.

Harmonic(简谐)

Harmonic motions start and end with maximum acceleration rates. This makes a poor motion to be used in conjunction with a dwell.

Displacement: $s = 0.5h(1 - \cos \pi \frac{\theta}{\beta})$

Velocity: $v = \frac{0.5 \pi h [\sin \pi (\theta / \beta)]}{T}$

Acceleration: $a = \frac{0.5 \pi^2 h [\cos \pi (\theta / \beta)]}{T^2}$

The value for n may be configured, which alters where the acceleration rate changes from positive to negative during the duration of the motion.

Modified Sine(修正正弦)

Curve Characteristics of the Modified Sine Curve:

From 0 to $\beta / 8$:

$$s = h(0.43990 (\theta / \beta) - 0.03501 \sin [4\pi (\theta / \beta)])$$

$$v = h[0.3890 - 0.3980 \cos 4\pi (\theta / \beta)]$$

$$a = h[4.88812 \sin 4\pi (\theta / \beta)]$$

From $\beta / 8$ to $\beta * 0.875$:

$$s = h[0.43990 (\theta / \beta) - 0.31505 \cos ((4\pi / 3)(\theta / \beta) - (\pi / 6)) + 0.28005]$$

$$v = h[0.43990 + 1.31967 \sin ((4\pi / 3)(\theta / \beta) - (\pi / 6))]$$

$$a = h[5.528 \cos ((4\pi / 3)(\theta / \beta) - (\pi / 6))]$$

From $\beta * 0.875$ to β :

$$s = h[0.56010 + 0.43990 (\theta / \beta) - 0.03501 \sin (2\pi [2(\theta / \beta) - 1])]$$

$$v = h[0.43990 (1 - \cos 2\pi [2(\theta / \beta) - 1])]$$

$$a = h(5.528 \sin 2\pi [2(\theta / \beta) - 1])$$

Modified Trapezoid(修正梯形)

Characteristics of the Modified Trapezoid Curve:

From 0 to $\beta / 8$:

$$s = h(0.3890 (\theta / \beta) - 0.03095 \sin [4\pi (\theta / \beta)])$$

$$v = h[0.3890 - 0.3980 \cos 4\pi (\theta / \beta)]$$

$$a = h[4.88812 \sin 4\pi (\theta / \beta)]$$

From $\beta / 8$ to $\beta * 0.375$:

$$s = h[2.44406 (\theta / \beta)^2 - 0.22203 (\theta / \beta) + 0.00723]$$

$$v = h[4.88812 (\theta / \beta) - 0.22203]$$

$$a = h(4.88812)$$

From $\beta * 0.375$ to $\beta / 2$:

$$s = h(1.61102 (\theta / \beta) - 0.03095 \sin (4\pi (\theta / \beta) - \pi) - 0.30551)$$

$$v = h(1.61102 - 0.38898 \cos [4\pi (\theta / \beta) - 2\pi])$$

$$a = h(4.88812 \sin [4\pi (\theta / \beta) - \pi])$$

From $\beta / 2$ to $\beta * 0.625$:

$$s = h(1.61102 (\theta / \beta) - 0.03095 \sin (4\pi (\theta / \beta) - \pi) - 0.30551)$$

$$v = h(1.61102 + 0.38898 \cos [4\pi (\theta / \beta) - 2\pi])$$

$$a = h(-4.88812 \sin [4\pi (\theta / \beta) - 2\pi])$$

Cycloidal/Harmonic(先摆线/后简谐)

The Cycloidal/Harmonic motion is a combination of a cycloidal and harmonic motion. The acceleration portion (from a dwell) is cycloidal and the deceleration is harmonic. This motion is normally used in conjunction with the Harmonic/Cycloidal motion. Dwell motions

normally precede and follow this set of motions. A rise and return cycle would be $\frac{1}{2}$ cycloidal acceleration to $\frac{1}{2}$ harmonic deceleration to $\frac{1}{2}$ harmonic acceleration to $\frac{1}{2}$ cycloidal deceleration.

Harmonic/Cycloidal(先简谐/后摆线)

The Harmonic/Cycloidal motion is a combination of a cycloidal and harmonic motion. The acceleration portion (starting from a Cycloidal/Harmonic motion) is harmonic and the deceleration is cycloidal (to dwell). This motion is normally used in conjunction with the Cycloidal/Harmonic motion. Dwell motions normally precede and follow this set of motions. A rise and return cycle would be $\frac{1}{2}$ cycloidal acceleration to $\frac{1}{2}$ harmonic deceleration to $\frac{1}{2}$ harmonic acceleration to $\frac{1}{2}$ cycloidal deceleration.

Constant Velocity(等速度)

A Constant Velocity motion has a set velocity during all or part of the motion. This velocity is equal to the maximum velocity of the motion. CamTrax64 allows for a motion to be specified for acceleration and/or deceleration. Cycloidal, harmonic, modified sine, cycloidal/harmonic, harmonic/cycloidal and constant acceleration motions may be used. The acceleration/deceleration portions may be symmetrical or asymmetrical.

Terminal Velocity(终端速度)

A Terminal Velocity motion has a constant velocity during a portion of the motion. Unlike the constant velocity motion, which has a set velocity at the maximum velocity, the terminal velocity has a specified velocity near the beginning or the end of the segment. This type of motion can be used for a press operation where greater forces are required near the beginning or end of the stroke. There may be some undesirable spikes in pulse at the transition to and from the constant velocity portion of the motion. Cycloidal, harmonic, modified sine and constant acceleration motions may be used.

Polynomial 8th Power Rise(多项式 8th 功率上升)

A Polynomial 8th Power Rise when used in conjunction with a Polynomial 8th Power Fall and a dwell makes a single dwell cam. The angle of each of the polynomials should be equal to each other to avoid any pulse at the transition between the two motions.

Polynomial 8th Power Fall(多项式 8th 功率下降)

A Polynomial 8th Power Fall when used in conjunction with a dwell and a Polynomial 8th Power Rise makes a single dwell cam. The angle of each of the polynomials should be equal to each other to avoid any pulse at the transition between the two motions.

Polynomial 345(多项式 345)

The Polynomial 345 is very similar to the Cycloidal motion. It has slightly less peak acceleration and velocity than the cycloidal motion.

Whereas the symmetry 'n' in a cycloidal motion can be specified there is no such option for the Polynomial 345.

Polynomial 4567(多项式 4567)

The Polynomial 4567 is similar to the Cycloidal motion but has a slower start. The peak velocity and acceleration rates are greater than the cycloidal motion. Whereas the symmetry 'n' in a cycloidal motion can be specified there is no such option for the Polynomial 4567.

Polynomial 3456 Rise(多项式 3456 上升)

The Polynomial 3456 Rise when coupled with the Polynomial 3456 Fall and a dwell makes for an acceptable single dwell cam. The angle of each of the polynomials should be equal to each other to avoid any pulse at the transition between the two polynomial motions. The symmetry 'n' value is not configurable.

Polynomial 3456 Fall(多项式 3456 下降)

The Polynomial 3456 Fall when coupled with a dwell and the Polynomial 3456 Rise makes for an acceptable single dwell cam. The angle of each of the polynomials should be equal to each other to avoid any pulse at the transition between the two polynomial motions. The symmetry 'n' value is not configurable.

Constant Acceleration(等加速度)

The Constant Acceleration motion has infinite pulse at the terminals and switches from positive to negative (or negative to positive) at the mid- point of the motion.

Double Harmonic Rise(双简谐上升)

The Double Harmonic Rise is similar to the Polynomial 3456 Rise but has a slightly greater peak velocity and acceleration rate. The symmetry 'n' value is not configurable.

Double Harmonic Fall(双简谐下降)

The Double Harmonic Fall is similar to the Polynomial 3456 Fall but has a slightly greater peak velocity and acceleration rate. The symmetry 'n' value is not configurable.

User Points(用户点)


User Points gives the user the ability to specify each point along the motion. The number of points must match the number of degrees of motion multiplied by the precision increment plus 1. To enter points first select the User Points motion type then press the Edit button in the configure column and to the right of the selection.

By Pass(跳过忽略)

The By Pass 'motion' leaves a blank for that segment of the path. A By Pass type cannot be used when creating the CAD model with a single surface path.

Create CAD Models and Assemblies...(创建 CAD 模型和装配)

To open the dialog window to create CAD models and Assemblies click on the menu item CAD>Create CAD Models and Assemblies or click on the Create Cad Models and Assemblies bar button.



Options for creating cams and/or assemblies(用于创建凸轮或装配的选项)

Create active cam and all paths. (创建活动凸轮和所有路径。)

Select this option to create the active cam and all paths associated with the cam. The CAD part file will not be saved automatically.

Create active path on current active CAD part file(在当前激活的 CAD 零件文件上创建活动路径)

Select this option to create only the active path on the active CAD part file. A CAD part file must be active. The path is created about the X, Y or Z axis that is used to define the cam blank.

💡 It is highly recommended that as many of the non-base features of the CAD part file be suppressed before adding the cam path.

Create all cams and assembly(创建所有凸轮和装配)

Select this option to have all cams created in CAD.

There are 3 options available when creating the assembly:

1. Add existing models to new assembly (do not recreate models with same name).
2. Overwrite existing models (existing models will be overwritten).
3. Overwrite any existing models and the assembly.

Path creation options(路径创建选项)

Each path may be created with one of the following 3 options:

Create single surface path only(仅创建单个路径表面)

This option will create the single surface path that can be used in CAD assemblies for use in animations. This allows the cam follower to be mated to the path for the full 360 degrees of rotation. The path must be a full 360 degrees and terminate where it starts.

Create individual path segments only(仅创建单独路径分割)

This option will create each individual path segment with its own loft or extrusion cut.

Create single surface path and individual segments

(suppressed) (创建单一表面路径和个别分割(压缩))

This option is a combination of the two other options. The individual segments will be suppressed as they are created leaving the single surface unsuppressed.

Browse CAD File Location(浏览 CAD 文件位置)

The CAD files may be saved in a location different from the CamTrax64 file location. Click the "Browse CAD File location" button and browse or create a new folder for the CAD files.

Create in "CAD"(在 CAD 中创建)

Press the "Create in CAD" button after making any desired changes to the settings.

The button text will change depending on which CAD is being used. The version number may be included in the button text depending on which CAD Version option is selected in the CamTrax64 Options properties.

Edit CAD Models(编辑 CAD 模型)

To open the dialog window to edit CAD models click on the menu item CAD>Edit CAD Models or click on the Edit Cad Models tool bar button. The background color of the display area will change to a light blue while CamTrax64 is in the edit mode. The Edit CAD Models tool window will remain on top of other windows.



Link(连接)

Press the Link button to read the cam data in the CAD file.

Update CAD(更新 CAD)

Update CAD updates the CAD part file with the revised data in the CamTrax64 component.

Cancel(取消)

Cancel will close the edit window.

Close(关闭)

Close will close the edit window.

Procedure to edit a cam model in CAD(编辑凸轮 CAD 模型的过程)

- 1) Open the cam part file open in CAD.
- 2) Click on the Link button to read the data from the CAD model.
If there is not an active component in CamTrax64 a new cam will be started. If there is an active component in CamTrax64, the internal identification of the CAD model and the CamTrax64 component will be compared. If they match, CamTrax64 will use the data for the cam that is open in CamTrax64. If they do not match, a message will be displayed and the cam data from the CAD file will not be read. The CamTrax64 component will need to be closed and the link button pressed again.
- 3) Make the required changes to the component in CamTrax64.
- 4) Press the Update CAD button to implement the changes to the CAD model.

If the updated model includes a new path, each individual segment will be created and suppressed. Then a single surface path will be created.

If the revised path has less segments than the original path, those extra segments will remain on the CAD file in a suppressed state. Those segments may be manually removed.

Tips on how to have a successful edit:

Never rename any of the CamTrax64 features. CamTrax64 uses these names to locate these features in the CAD model. This includes names of lofts, extrudes, sketches, guide curves and dimensions.

If the model is manually modified, always do so by adding or subtracting to the features created by CamTrax64. Do not directly modify a CamTrax64 created sketch. For example, a stepped bore is required in the final part. Do not modify the sketch created by CamTrax64. Rather, start a new sketch and then extrude or revolve it.

Limitations to editing CAD models(编辑 CAD 模型的局限性)

1. A path on a surface cannot be changed to another surface.
2. The axis of the cam cannot be changed.

Fabrication(加工)

The Fabrication properties may be activated for the active path by clicking the Fabrication>Activate Fabrication menu item.

Finishing Tool(精加工工具)

Diameter Finishing(直径精加工)

Diameter Finishing specifies the diameter of the tool used for cutting the finish passes.

Feed Rate Finishing(进给速率精加工)

Feed Rate Finishing determines the rate of feed for the finish passes.

Stock for Finishing(坯料精加工)

Stock for Finish determines the amount of stock the roughing passes

leave for the finish passes.

Tool Number Finishing(工具号码精加工)

Tool Number Finishing determines which tool number will be selected for finishing. This assumes the machining center has a tool changer.

Depth Cuts Finishing(深度切割精加工)

Depth Cuts Finishing determines the number of depth cuts which will be made to cut the full depth of the path.

Number of Passes Finishing(程数精加工)

Number of Passes Finishing determines how many finish passes will be made to cut the remaining stock that the rough cut left.

Spindle Speed Finishing(主轴转速精加工)

Spindle Speed Finishing determines the RPM of the tool for the finish passes.

Roughing Tool(粗加工工具)

Diameter Roughing(直径粗加工)

Diameter Roughing specifies the diameter of the tool used for cutting the rough passes.

Feed Rate Roughing(进给速率粗加工)

Feed Rate Roughing determines the rate of feed for the rough passes.

Tool Number Roughing(工具号码粗加工)

Tool Number Roughing determines which tool number will be selected for rough passes. This assumes the machining center has a tool changer.

Depth Cuts Roughing(深度切割粗加工)

Depth Cuts Roughing determines the number of depth cuts which will be made to cut the full depth of the path.

Spindle Speed Roughing(主轴转速粗加工)

Spindle Speed Roughing determines the RPM of the tool for the rough

passes.

Cuts(切割)

Surfaces to Cut(表面切割)

Select between:

Center Only

Center, Upper and Lower Surfaces Upper or Outer Surface Only

Lower or Inner Surface Only Center, Upper and Lower Surfaces

Cuts(切割)

Select between:

Finish Cut Only

Rough Cut Only

Finish and Rough Cuts

Feed Rate Z(进给速率 Z)

Feed Rate Z controls the rate of feed for the Z axis when not in a rapid move.

Mill Direction(铣刀方向)

Select between:

Climb Mill Conventional Mill

Coolant(冷却液)

Select between:

None

Flood

Mist

Controller(控制器)

Machine Controller(机器控制器)

There are three controllers available. Select between:

Generic G Code

HAAS

MAZAK

Please contact Camnetics support if you would like another controller added.

Program Number(程序号)

Program Number defines the number that will be assigned to the program.

Mirror X Direction(镜像 X 方向)

Mirror X Direction is a user set true or false property. It may be necessary for the CNC machine setup to mirror the X axis.

Mirror Y Direction(镜像 Y 方向)

The Mirror Y Direction is a user set true or false property. It may be necessary for the CNC machine setup to mirror the Y axis.

Mirror A Direction(镜像 A 方向)

The Mirror A Direction is a user set true or false property. It may be necessary for the CNC machine setup to mirror the A axis.

Simulate Fabrication(模拟加工)

Simulate Fabrication allows the user to view a NC (numerical control) file created by CamTrax64 in action.

To Open the fabrication module, click on the GearTeq menu item Fabrication>Simulate Fabrication.



The text window will display about 20 lines of the NC program. The current line will be preceded by "@ Line" and the line number in the NC file.

Buttons(按钮)

Open(打开)

Use the Open button to open a previously created NC file.

Edit(编辑)

Pressing the Edit button opens the NC file in Notepad so it can be edited or viewed in its entirety. While the file is open in Notepad CamTrax64 will be in a wait mode until Notepad is closed.

Close(关闭)

Press the Close button to close the Simulation window.

VCR Controls(VCR 控件)

|| Pause. If the "||" button is pressed while the program is being executed the program will halt at the current position.

J Jump out of sub-routine. If the "J" button is press while the simulation is being executed in a sub-routine, the program will jump to near the end of the routine.

|<< Go to first line. Pressing the "|<<" button will force the program to stop and reset to the first line.

< Go back one line. If the "<" button is pressed the program will take one step backwards.

>> Run NC program. If the ">>" button is pressed the program will run from its current position.

> Go ahead one line. If the ">" button is pressed the program will step ahead one line.

Tool Bars(工具栏)

Insert(插入)

 Add New Cylinder to Assembly

 Add New Cube to Assembly


 Insert Path

 Add Segment

Standard(标准)

 New

 Open

 Save Active Component

 Save All

 Print the CamTrax64 Window

 Create CAD Models and Assembly

 Edit CAD Models

 Open Chart Window

 Open Machine Layout

Standard Views(标准视图)

 Front

Front changes the view orientation to Front at the current view scale.

 Back

Back changes the view orientation to Back at the current view scale.



Left

Left changes the view orientation to Left at the current view scale.



Right

Right changes the view orientation to Right at the current view scale.



Top

Top changes the view orientation to Top at the current view scale.



Bottom

Bottom changes the view orientation to Bottom at the current view scale.



Isometric

Isometric changes the view orientation to Isometric at the current view scale.



Index X Left

Index X Left changes the view orientation up by the spin increment specified in the Options.



Index X Right

Index X Right changes the view orientation up by the spin increment specified in the Options.



Index Y Left

Index Y Left changes the view orientation up by the spin increment specified in the Options.



Index Y Right

Index Y Right changes the view orientation up by the spin increment specified in the Options.



Index Z Left

Index Z Left changes the view orientation up by the spin increment specified in the Options.



Index Z Right

Index Z Right changes the view orientation up by the spin increment specified in the Options.

View(视图)



Last View

Last View changes the view orientation to previous view.



Zoom to Fit

Zoom to Fit changes the current view orientation to fit inside of the window.



Zoom Area

Zoom Area allows the user to draw a box over an area to be displayed at full screen.



Zoom In Out

Zoom In Out allows the user to use the mouse left button to zoom in or out by dragging the cursor on the screen. Dragging the cursor vertically up increases the scale of the display. Dragging the cursor down decreases the scale of the display. The amount of change can be increased by dragging from the upper left hand corner to the lower right hand corner. Conversely, the change can be decreased by dragging from the upper right hand corner to the lower left hand corner.



Rotate the View

Rotate the View allows the user to rotate the view by using either the mouse left or middle buttons to drag the cursor on the screen.



Pan

Pan allows the user to move the view by using either the mouse left or middle buttons to drag the cursor on the screen.



Drive

Drive allows the user to drive the components by using the mouse left button to drag the cursor on the screen.

Simulation(模拟)



Stop

Stop will stop a running simulation.



Reset to 0

Reset to 0 will set the cam angle of all cams to 0.



Back

Back will drive the components back one spin increment. Set the spin increment in the options menu.



Play

Play will drive the components for a short simulation.



Forward

Forward tool drive the components forward one spin increment. Set the spin increment in the options menu.

Mouse controls(鼠标控制)

Current Mouse Position(当前鼠标位置)

The status bar at the bottom of the screen displays the current mouse position relative to the origin of the currently active component. All coordinates are normal to the screen.

On Screen Measurements(屏幕上测量)

Right click and move for on screen measurements. This is an easy way to get an approximate measurement from the drawing window. All measurements are normal to the screen. The status bar at the bottom of the CamTrax64 window displays all measurements.

Mouse wheel(鼠标滚轮)


Wheel up and down scales the view of the components. All scaling is done from the center of the screen, not the mouse position. Pan the geometry to the center of the screen then use the mouse wheel to enlarge or reduce the view scale. The direction of the mouse wheel is controllable by a setting in the Options menu.

Middle Mouse Button (wheel) (鼠标中键 (滚轮))

Drag the view with the middle button held down. The wheel can be rotated at the same time to zoom the view.

Chart(图表)

The Chart window displays the current active path.




Displacement, velocity, acceleration, pressure angle, torque, normal force, radius of curvature, stress contact and pulse (jerk) may be selected for each of the 4 charts. In addition, the top chart has a layout chart. This shows the displacement of each of the segments in a straight line rather than the displacement curve.

Each of the charts has a slider bar that can be dragged to a new position. The box on the left of each chart displays the angle of the cam slider bar and the value associated with that angle. To drag the bar to a new position, place the cursor over the line, hold down the left mouse button and drag it to a new position.

Machine Layout(机构布局)

The Machine Layout window can display 6 different cam paths at a time.




Cam Design 101(凸轮设计)

Common Cam Design Errors(常见凸轮设计错误)

Under Cutting(下切割)

Under Cutting is a condition that presents itself often in cam design. Designers are almost always constrained in the amount of space they have to create a cam of adequate size. CamTrax64 can visually help find these problem areas.



Under Cutting of a Disk Cam

Changing any number of the cam and path parameters can help to rectify these occurrences. For example:

- Smaller cam follower
- Larger cam
- Additional segment angle
- Increasing the offsets

Motion types that should not follow one another

Cycloidal to cycloidal

Harmonic to cycloidal

Configuring a Constant Velocity Motion Type(配置等速度运动类型)

Parameters:

Cam RPM: 60

Cycle time: 1.00 seconds

Minimum constant velocity displacement required: 3.50 inches

Constant velocity speed: 16.00 inches per second

Start a new cam by opening the Sample Cams>Single Dwell>Disk sample cam.

Change the first motion type from Cycloidal/Harmonic to Constant Velocity.

Edit the Configure Constant Velocity dialog window by clicking on the Edit button to the right of the motion type.

In the b paragraph, change the Accel_Decel_Type from Cycloidal to Cycloidal/Harmonic.

Change the Velocity of CV to 16.00 inches per second.

Note that the Displacement line is charted without any acceleration or deceleration. This would make an unacceptable cam motion.

Try changing the End Offset from 6.0000in to 5.7500in, and then reopen the Edit dialog window. Note that there is now a small section of acceleration and deceleration but the Displacement of CV is at 3.42in which is less than the 3.500 minimum required.

Close the dialog window and change the End Offset back to 6.0000in and change the End Angle to 110.0 degrees.


Reopen the Edit dialog window. Check that 16.00in/sec is specified for the Velocity of CV. Note that the Displacement of CV is at 2.82in, which is far below the required 3.5n inches.

Close the edit dialog window and change the End Offset to 6.50in

Reopen the Edit dialog window. Check that 16.00in/sec is specified for the Velocity of CV. Note that the Displacement of CV is at 3.982in, which is above the required 3.5n inches.

The Displacement at CV can be reduced by changing the End

Offset to 6.30inches. The will provide 3.52 inches of constant velocity displacement at 16.00in/sec.




Other changes to the cam parameters will be required to reduce the pressure angle.

Configuring a Terminal Velocity Motion Type(配置终端速速运动类型)

The CamTrax64 Terminal Velocity motion allows the designer to insert a section of constant velocity into a standard cam motion. The section of constant velocity may be inserted near the beginning or the end of the motion.

To put it simply, CamTrax64 calculates the velocity along the motion until it finds the velocity that matches the constant velocity value. It uses that constant velocity for the prescribed distance and then completes the standard motion.

The type of motion used within the terminal velocity will affect the amount of cam angle and offset before the start of the constant velocity.



The above example is from a 90 degree segment that starts at 5.00 offset and falls to 1.00 offset.

The properties in bold maybe changed by the designer.

Select the Motion Type to be used for acceleration and deceleration.

Select either At Start of Segment or At End of Segment for the placement of the section of constant velocity.

Changing the Displacement of TV will also change the Velocity of TV value.

Changing the Velocity of TV will also change the Displacement of TV value.

Changing the Time of TV will also change the Angle of TV value. The value entered must be less than the segment time.

Changing the Angle of TV will also change the Time of TV value. The value entered must be less than the segment angle.

The Chart Type drop down box allows the user to select between a number of different chart types to be displayed in the graphic window.

The magenta slider bar can be dragged left and right. Values for the position of the slider bar are displayed in the text box below the graphic window.

--交流 QQ 群--

CamTrax64 汉化群(182945602)

GearTeq 汉化群(182945790)

SolidWorks 技术交流(133712153)

SolidWorks 机械 3D 化(133713690)

--下载及更新--

汉化版下载及更新地址：

<http://pan.baidu.com/share/link?shareid=4292486867&uk=621663628>

--问题反馈及建议--

邮箱：hua200905@qq.com

QQ 空间：<http://user.qzone.qq.com/991421914>